



To use GPIO2 as an input
In setup() make GPIO0 an output and LOW
i.e.

```
void setup() {
    pinMode(0,OUTPUT);
    digitalWrite(0,LOW);
    ...
}
```